X_1 = Height of Backwall (with no approach slab)
   = Slab + Haunch + Beam + Brg Pad + Brg Buildup
X_2 = Height of Backwall (with approach slab)
   = Deduct thickness of approach slab (1'-1" typical) from X_1

Fig. 3-3